

BMW NBT wiring diagram





DIP switch settings

8.8"/10.25" 6.5"

Setup notes

Unplug the interface power harness before changing DIP switches.

[1]

NUMBERED DIAGRAM NOTES

[1] External microphone: switch 7 ON.

[2] Bluetooth antenna